

Caspian **CR7** Remote Control



The CR7 Remote Control is used for both the Caspian CD Player and Integrated Amplifier. The top section is dedicated to the Integrated Amplifier and the lower section to the CD Player.

Integrated Amplifier Functions

Mode: Takes the amplifier out of/into standby mode.

Mute: Reduces the volume by -20dB

Input ◀: Select input left

Input ▶: Select input right

Volume ▽: Volume down

Volume ▲: Volume up

CD Player Functions

CD ◻: Stop

CD ▶||: Play/Pause

Track ◀: Skip to previous track

Track ▶: Skip to next track

Fast ◀◀: Rewind

Fast ▶▶: Fast Forward

Repeat:

Press once to repeat all tracks

Press again to repeat current track

Press again to cancel repeat mode

Shuffle:

When in Stop mode, press Shuffle to play the tracks in a random order. To cancel press ◻



CAUTION

Danger of explosion if battery is incorrectly replaced.

Replace only with the same or equivalent type.



WARNING

Do not ingest the battery, Chemical Burn Hazard.

This remote control contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Roksan Audio

24 Brook Road, Rayleigh, Essex, SS7 7XJ, United Kingdom

www.roksan.co.uk

ROK-1338 CR7 V1.1